

BON VOR	BON AN/AUS	AUSZAHLUNG	EINZAHLUNG	£	1	€	7	■	13	19	25	31	37	43	49	(PAGE1)	BED.#
#/KV	LÖSCHEN	PLU	X	!	2	@	8	#	14	20	26	32	38	44	50	)	RECHN #
VOID	7	8	9	Q	3	W	9	E	15	21	27	33	39	45	51	P	SALDO (↑)
RÜCKNAHME	4	5	6	A	4	S	10	D	16	22	28	34	40	46	52	;	KREDIT 1 (↓)
SOFORT STORNO	1	2	3	Z	5	X	11	C	17	23	29	35	41	47	53	/	ZWS
BON STORNO	0	00	.	+	6	-	12	<	18	24	30	36	42	48	54	BACKSPACE	BAR ENTER